



## ASSEMBLY AND USER MANUAL

### 1. Specification

no.	Amount of parts	Description
1	2	Padding 1800
2	16	Self drilling screw with hexagon head 5.5x25mm
3	8	PU washer
4	3	Connecting rod

### 2. Assembly

- Installation should be only done after ensuring the backboard is assembled properly
- Use only a portable drill with adjustable clutch release
- Place the self-tapping screw with PU washer on the socket wrench
- Push the padding against the backboard
- Drill the screw to the frame of the backboard through the mounting hole and tighten till the drill clutch starts working.

- First, screw in the side part of the padding and then its lower part
- Fix together the connecting roads of both paddings and repeat all the steps on the second padding
- Clean floor area of all drill shavings, etc. to eliminate the possibility of injuries or floor damage
- Installation requires two capable adults

### 3. Method of use:

- The padding is suitable for the backboards with the dimensions 1800x1050x55mm and should be used for this purpose only. It is designed for both indoor and outdoor backboards.
- Periodically check mounting elements of the padding and the condition of its surface
- Prevent mechanical damages such as slitting, cutting, exposing to fire etc.
- While moving the backboard do not use the padding as a handle
- Do not hang on the padding
- Do not use the padding as transport protection
- Cleaning can be performed with commonly available cleaning agents
- Do not use solvents or caustic agents while cleaning